



Short manual



Kurzanleitung

DELOCK®
we move the world

Cable USB 2.0 type A male > USB 2.0 type B male

Installation

1. Connect the USB 2.0 cable to a free active USB port of your notebook or PC.
2. Connect your USB device to the USB female port of the cable.
3. For operation of active USB devices, e.g. printer, you require an additional power supply for the connected device.
4. The device is now ready to use.

Installation

1. Stecken Sie das USB 2.0 Verlängerungskabel an einen freien aktiven USB Port Ihres Notebooks oder PCs.
2. Verbinden Sie nun Ihr USB Gerät mit der USB Buchse des Anschlusskabels.
3. Für den Betrieb von aktiven USB Geräten, wie z. B. Drucker, benötigen Sie ein zusätzliches Netzteil für das angeschlossene Gerät.
4. Das Gerät kann nun verwendet werden.

Support Delock

If you have further questions, please contact our customer support:
support@delock.de

You can find current product information on our homepage: www.delock.com

Final clause

Information and data contained in this manual are subject to change without notice in advance. Errors and misprints excepted.

Copyright

No part of this user manual may be reproduced, or transmitted for any purpose, regardless in which way or by which means, electronically or mechanically, without explicit written approval of Delock.

Edition: 08/2014



Product-No:82915/83557
User manual no:82915
www.delock.com

Declaration of conformity

Products with a CE symbol fulfill the EMC directive (2004/108/EC), which were released by the EU-comission.

The declaration of conformity can be downloaded here:

<http://www.delock.de/service/conformity>

WEEE-notice

The WEEE (Waste Electrical and Electronic Equipment)-directive, which became effective as European law on February 13th 2003, resulted in an all out change in the disposal of disused electro devices. The primarily purpose of this directive is the avoidance of electrical waste (WEEE) and at the same time the support of recycling and other forms of recycling in order to reduce waste. The WEEE-logo on the device and the package indicates that the device should not be disposed in the normal household garbage. You are responsible for taking the disused electrical and electronical devices to a respective collecting point. A separated collection and reasonable recycling of your electrical waste helps handling the natural resources more economical. Furthermore recycling of electrical waste is a contribution to keep the environment and thus also the health of men. Further information about disposal of electrical and electronical waste, recycling and the collection points are available in local organizations, waste management enterprises, in specialized trade and the producer of the device.

Compliance with RoHS

This product complies with the directive 2011/65/EU of the European parliament and the council from January 3rd 2013 concerning the restricted use of dangerous substances in electrical and electronical devices (RoHS) as well as its modification.

